

CLEARVIEW TOWING MIRRORS (ELECTRIC POWER ADJUSTABLE)

CV-LR-D34-EB / CV-LR-D34-IEB

Page: 1 OF 4

Instructions for Installation on:
Land Rover LR3 2005 - 2009

Clearview's premiere line of replacement towing mirrors offers superior design, style, and feature-rich functions to meet your needs! Clearview Towing Mirrors are full replacement towing mirrors and should be your next upgrade if you're doing any repeated towing with your Land Rover LR3.



WATCH VIDEO INSTALL!



SCAN to Watch!



Direct Link:
<https://tr.im/1faTl>



1. First the door panel must be removed to access the side mirror connector: Using a pocket screwdriver, pry the Land Rover Emblem from door panel. Remove screw that is uncovered.

HOW-TO INSTALL

Page: 2 OF 4

2. Behind the door handle, pry off the small round cover, using a pocket screwdriver, to reveal a screw. Remove screw.



3. Remove the cover on the door panel arm rest using a pocket screwdriver.

4. Remove the 4 screws that are revealed.



5. Remove the two philips head screws at the bottom of the door tray.

HOW-TO INSTALL

Page: 3 OF 4

6. Loosen speaker housing.



7. Pop off the door panel, leaving everything connected.

8. Now you have access to mirror connector, which you will disconnect.



9. Run out the three bolts holding the mirror in place, taking caution to support the mirror, so not to drop it.

HOW-TO INSTALL

Page: 4 OF 4

10. Remove original mirror, snaking connector harness through the opening.



11. Install the New Clearview Towing Mirror, guiding wiring through opening and secure the top bolt, first, to hold. Then, secure bottom 2 bolts with 10mm socket.

12. Plug in the connector. The Mirror is now installed.



13. Reverse to process to reinstall door panel. Now use the process again to install the opposite mirror. Done!